

<p>1</p> <p>A</p> <p>F</p> <p>B</p>	<p>2</p> <p>D</p> <p>C</p> <p>E</p>				
<p>Ax1</p>	<p>Bx1</p>	<p>Cx1</p>	<p>Dx1</p>		
			<table border="1" data-bbox="1208 1937 1495 2148"> <tr> <td data-bbox="1208 1937 1353 2033"> <p>Ex5</p> </td> <td data-bbox="1353 1937 1495 2033"> <p>Fx3</p> </td> </tr> </table>	<p>Ex5</p>	<p>Fx3</p>
<p>Ex5</p>	<p>Fx3</p>				



EN Seat height adjustment with the right lever

FR Réglage de la hauteur de l'assise avec le levier droit

PL Regulacja wysokości siedziska za pomocą prawej dźwigni



EN Adjustment of intensity with the lower knob

FR Réglage de l'intensité avec le bouton inférieur

PL Regulacja natężenia pokrętkiem dolnym



EN Synchronized adjustment of the tilt angle of the backrest and seat using the right lever

FR Inclinaison synchrone du dossier et de l'assise avec le levier droit

PL Synchroniczne odchylenie oparcia i siedziska prawą dźwignią



EN Adjustment of lumbar support in height and depth

FR Réglage du support lombaire en hauteur et en profondeur

PL Regulacja podparcia lędźwiowego na wysokość i głębokość